



B-122E

- Exit Push Button With form "C" Contact, White (EB-12)